


# Air intake Pressure Sensor, Volvo Articulated Hauler, Wheel Loader & Excavator

---



**PRODUCT NO.:** 20524936

**Condition:** New

**Brand:** Volvo



## Description

Suitable for following Volvo Machines: **Volvo Wheel Loader**

L90E Volvo, L70E Volvo, L60E Volvo, L110E Volvo, L120E Volvo, L350F Volvo, L60F Volvo, L70F Volvo, L90F Volvo, L110F Volvo, L120F Volvo, L120G Volvo, L70G Volvo, L105 Volvo, L120H Volvo, L70H Volvo, L60G Z Volvo, L120G Z Volvo, L120E Volvo, L90G Z Volvo, L90H Volvo, L60H Volvo, L110H Volvo, L90G Volvo, L60G Volvo, L110G Volvo, L110E Volvo, L120E Volvo, L60E OR Volvo, L70E OR Volvo, L90E OR Volvo, L45H Volvo, L50H Volvo, L50G Volvo, L45G Volvo

**Volvo Articulated Hauler** A25D Volvo, A30D Volvo, A25E 4x4 Volvo, A30E Volvo, A40E FS Volvo, A40E Volvo, A25E Volvo, A25D 4x4 Volvo. **Volvo Excavator** EC160B LC Volvo, EC180B LC Volvo, EW140B Volvo, EW145B Volvo, EC290B LC Volvo, EC290B NLC Volvo, EC290B LC Volvo, EC290B NLC Volvo, EC240B LC Volvo, EC240B NLC Volvo, EC240B LC Volvo, EC240B NLC Volvo, EC135B LC Volvo, EC160C NL Volvo, EC160C NL Volvo, EC180C L Volvo, EC210C NL Volvo, EC210C LR Volvo, EC210C L Volvo, EC210C N Volvo, EC210C LD Volvo, EC240C LD Volvo, EC240C L Volvo, EC290C LR Volvo, EC290C LD Volvo, EW140C Volvo, EW180C Volvo, EC235C NL Volvo, EC235C NL Volvo, FC2421C Volvo, FC2924C Volvo, ECR145C L Volvo, ECR235C L Volvo, EC700C L Volvo, EC140C L Volvo, EC140C L Volvo, FC2121C Volvo, EW210C Volvo, EC700B HR Volvo, ECR305C L Volvo, EC290B LR Volvo, EC210B LR Volvo, EC210B NC Volvo, EC210B NLC Volvo, EC210B LR Volvo, EC210B NC Volvo, EC210B NLC Volvo, EC240B LC Volvo, EC240B NLC Volvo, EC140B LCM Volvo, EC180B LC Volvo, EC300D L Volvo, EC300D LD Volvo, EC300D L Volvo, EC300D LD Volvo, EC250D L Volvo, EC250D NL Volvo, EC250D L Volvo, EC250D NL Volvo, EW160D Volvo, EW210D Volvo, EC220D Volvo, EC220D LR Volvo, EC235D NL Volvo, EC350D Volvo, EC350D Volvo, EC350D Volvo, EW205D Volvo, EC250E LR Volvo, EC250E LD Volvo, EC300E L Volvo, EC300E NL Volvo, EC300E NLD Volvo, EW180E Volvo, EC220E LR Volvo, EC220E NL Volvo, EC170D L Volvo, EC140E L Volvo, EC160E L Volvo, EC180E L Volvo, ECR145E L Volvo, EWR150E Volvo, EC210D LR Volvo, EC210D Volvo, EC210D L Volvo, EC200D Volvo, EC290B LR Volvo, EC240B LC Volvo, EC240B NLC Volvo, EC210B LC Volvo, EC210B NC Volvo, EC210B FX Volvo, EC140B LCM Volvo, EC140B LC Volvo, EC210B NLC Volvo, EC210B LR Volvo, EC210B F Volvo, EC240B LR Volvo, EC290B NLC Volvo, EC290B LC Volvo, EC200D Volvo, EC210D LR Volvo, EC210D L Volvo, EC210D Volvo, EW140E Volvo, ECR235E L Volvo, EC160E NL Volvo, EC140E LM Volvo, EC170D Volvo, EC170D Volvo, EC220E NH Volvo, EC220E N Volvo, EC220E L Volvo, EW160E Volvo, EC300E LD Volvo, EC300E LR Volvo, EC250E NLD Volvo, EC250E NL Volvo, EC250E L Volvo, EC350D L Volvo, ECR235D L Volvo, EC220D NL Volvo, EC220D N Volvo, EC220D L Volvo, EW180D Volvo, EC250D LR Volvo, EC250D Volvo, EC250D LR Volvo, EC250D Volvo, EC300D LR Volvo, EC300D NL Volvo, EC300D LR Volvo, EC300D NL Volvo, EC200B Volvo, EC160B LC Volvo, EC140B LC Volvo, EC240B LR Volvo, EW145B Volvo, EC210B Volvo, EC210B F Volvo, EC210B LC Volvo, EC210B Volvo, EC210B F Volvo, EC210B LC Volvo, EC290B LC Volvo, EC700C HR Volvo, EW230C Volvo, FC2121C Volvo, EC140C LM Volvo, EC700C LD Volvo, ECR235C L Volvo, ECR145C L Volvo, FC3329C Volvo, FC2421C Volvo, EC235C LD Volvo, EW180C Volvo, EW160C Volvo, EW140C Volvo, EC290C NL Volvo, EC290C L Volvo, EC240C NL Volvo, EC240C LR Volvo, EC210C LR Volvo, EC210C NL Volvo, EC210C LD Volvo, EC210C N Volvo, EC210C L Volvo, EC180C L Volvo, EC160C L Volvo, EC240B FX Volvo, EC240B LR Volvo, EC240B FX Volvo, EC240B LR Volvo, EC290B FX Volvo, EC290B LR Volvo, EC290B FX Volvo, EC290B LR Volvo, EC700B LC Volvo, EW200B Volvo, EW140B Volvo, EC160B NLC Volvo, EW180B Volvo, EW160B Volvo.

## Gallery